

Maintenance Pumpfix F

Article information

Item no.: 80118
GTIN:
Price group: 00

Description

Maintenance of the backwater pumping station Pumpfix F, exposed installation / floor slab installation

Scope of services (all work is carried out according to the inspection card):

- Functional check
- Removing the locking cover and inspecting the cover seals
- Removing the flap, inspecting the flap seal, cleaning the components
- Inspecting the electrical system components
- Greasing the moving parts
- Assembling the system
- System must be handed over in a safe operational state
- The recorded values are documented in a maintenance report

Requirements on site:

- Contact person must be on site
- Access to the system and control unit
- A hose water connection must be provided nearby

Note:

- Regular maintenance is a prerequisite for the warranty and insurance cover

Not included are costs for:

- Material expenses over 20 euros
- Any additional incidental expenses are charged based on the expenses incurred
- Difficult conditions, repair services, additional work
- Wasted journeys despite prior notice

Backwater valves must be serviced every six months by a specialist company in accordance with DIN 1986-3.

The price stated is for each maintenance operation.

From the commissioning to the execution of the service, a processing time of 10 working days should be expected.